




ALLVIEW®

SOUL X6 mini

EN	USER MANUAL.....	4
RO	MANUAL DE UTILIZARE.....	18
BG	РЪКОВОДСТВО ЗА УПОТРЕБА.....	33
CZ	UŽIVATELSKÝ MANUÁL.....	48
DE	BETRIEBSANLEITUNG.....	67
ES	MANUAL DE USUARIO	82
HU	HASZNÁLATI UTASÍTÁS	97
PL	INSTRUKCJA OBSŁUGI	108



EN	RO	BG	CZ
1 Power button	1 Buton pornire	1 Бутонът за захранване	1 ON/OFF Tlačítko
2 Speaker	2 Difuzor	2 говорител	2 Reprodaktor
3 Micro USB	3 Mufă micro USB	3 Микро USB	3 Micro USB
4 Flash	4 Flash	4 флаш	4 Blesk
5 Volume buttons	5 Butoane volum	5 сила на звука	5 Tlačítka hlasitosti
6 Earphones jack	6 Mufă căști	6 слушалки жак	6 Sluchátka jack
7 Notification LED	7 Led notificare	7 Светодиод за уведомяване	7 LED upozornění
8 Main camera	8 Cameră principală	8 Назад камера	8 Zadní fotoaparát
9 Front camera	9 Cameră frontală	9 Предна камера	9 Přední fotoaparát
10 Proximity sensor	10 Senzor de proximitate	10 Сензор за близост	10 Senzor blízkost
11 Fingerprint sensor	11 Senzor de amprentă	11 Пръстови отпечатащи	11 Senzor otisku prstu
DE	ES	HU	PL
1 Ein- / Ausschalter	1 Botón de encendido	1 Bekapcsoló gomb	1 Przycisk zasilania
2 Redner	2 Altavoz	2 Hangszóró	2 Głośnik
3 Micro USB	3 Micro USB	3 Micro USB	3 Micro USB
4 Blitz	4 Flash	4 Vaku	4 Błyskać
5 Lautstärketasten	5 Volumen	5 Hangerő gombok	5 Przyciski głośności
6 Kopfhörerbuchse	6 Enchufe auriculares	6 Fülhallgató jack	6 Słuchawki jack
7 Benachrichtigungs-LED	7 LED de notificación	7 Értésítési LED	7 Powiadomienie LED
8 Hauptkamera	8 Cámara trasera	8 Hátulsó kamera	8 Tylna kamera
9 Vordere Kamera	9 Cámara frontal	9 Elülső kamera	9 Aparat z przodu
10 Näherungssensor	10 Sensor de proximidad	10 Közelség érzékelő	10 Czujnik zbliżeniowy
11 Fingerabdruck Sens.	11 Sensor de huella digital	11 Ujjlenyomat-érzékelő	11 Czujnik odcisków palców

Notices for the use of phone

CAUTION! Please read carefully these instructions and follow them, in the case of dangerous situations.

Driving safety: It is recommended not to use the phone while driving. If you use it however, turn on the Handsfree mode.

Turn off your phone while in an aircraft.

Interference caused by mobile phones affects aviation safety, and thus is illegal to use it on the plane. Please make sure that your mobile phone is turned off when you are on the plane.

In hospital: When using the phone in a hospital, you must submit to the relevant rules specified by the hospital. Any interference caused by wireless devices may affect the performance of the phone.

Approved service: Only approved repair shops can repair mobile phones. If you open the phone and try to fix it yourself you will void the warranty of the product.

Accessories and batteries: Only accessories and batteries approved by the producer can be used.

Emergency calls: Make sure the phone is turned on and enabled if you wish to make an emergency call. Press the call key and confirm the location, explain what happened and do not close the call.

The battery and charging the battery: It is recommended to fully charge before the first use of the device.

The battery is not removable. Do not puncture or damage the battery in any way. Do not expose/keep/store close to heat sources/in sunlight. Risk of explosion.

Do not expose the battery/product to temperatures above 40° C. Do not dispose the battery/product in fire or drop anywhere. Return defective batteries/products in special centers or to the supplier center.

Warning: We take no responsibility for situations where the phone is used other than as provided in the manual. Our company reserves the right to make changes in the content of the manual without making this public. These changes will be posted on the company website to the product it amends.

The contents of this manual may differ from that in the product. In this case, the latter will be considered. To avoid the problems that might occur with the service shops approved by Visual Fan Ltd. (because Visual Fan reserves the right to stop the collaboration with any service shop which was previously approved and mentioned in the warranty card on the date on which the product batch was sold on the market), before taking a product to the service shop, please check the updated list of approved service shops on Allview website at the section: "Support&Service – Approved service". For more product details visit www.allviewmobile.com.

Do not cover the antenna with your hand or other objects. Failure to comply results in connectivity issues and rapid discharge of the battery.

All applications provided by third parties and installed in this device may be modified and/or stopped at any moment. Visual Fan Ltd will not be responsible in any way for modifications of the services or content of these applications. Any request or question regarding third party applications may be addressed to the owners of these applications.

Due to the used enclosure material, the product shall only be connected to a USB interface of version 2.0 or higher. The connection to the so called power USB is prohibited.

The adapter shall be installed near the equipment and shall be easily accessible.

Do not use the mobile phone in an environment with too high or too low temperature, never expose the mobile phone under strong sunshine or too a wet environment.

The maximum operating ambient temperature of the equipment is 40°C.

CAUTION! RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

This device has been tested and meets applicable limits for Radio Frequency (RF) exposure. Specific Absorption Rate (SAR) refers to the rate at which the body absorbs RF energy. SAR limits are 1.6 Watts per kilogram (over a volume containing a mass of 1 gram of tissue) in countries that follow the United States FCC limit and 2.0 W/kg (averaged over 10 grams of tissue) in countries that follow the Council of the European Union limit. Tests for SAR are conducted using standard operating positions with the device transmitting at its highest certified power level in all tested frequency bands. To reduce exposure to RF energy, use a hands-free accessory or other similar option to keep this device away from your head and body. Carry this device at least 5 mm away from your body to ensure exposure levels remain at or below the tested levels. Choose belt clips, holsters, or other similar body-worn accessories which do not contain metallic components, to support operation in this manner. Cases with metal parts may change the RF performance of the device, including its compliance with RF exposure guidelines, in a manner that has not been tested or certified, and use of such accessories should be avoided.

For your safety, it is recommended that, during charging, you don't keep the device near your body, and that you place it on an inflammable stand. We recommend that, during nighttime, you put the phone away from you at a minimal distance of 1 meter.

Device power on/off and standby

After inserting the SIM card, memory card and battery (optional), start the phone by holding down the Power button for 3 seconds. To power off, press and hold the same button and confirm. If you press the Power button, you will set phone in standby mode. To return shortly, press the same button.

Unlocking, idle screen and applications menu

To unlock the screen when resuming from standby, slide your finger from the bottom to the top of the screen. The main screen will be displayed. Home screen pages can be customized with shortcuts and widgets. At the top of the screen there is the notification bar that contains information about the mobile network signal, WiFi, Bluetooth, battery level, time and events.

To display the applications menu, touch the Menu icon from the bottom of the main screen. Slide the screen up to scroll through the main menu. Touch the desired application icon to access it. Use the Back button to return to the main screen.

Dialing

To call a number, from the main screen, open the dialer, dial the number and press the call key.

To answer a call, drag the icon to the right, and to reject the call drag the icon to the left.

You can call numbers directly from Call log, touch the dial symbol from the right side of the desired number.

Messaging

To create and send an SMS, proceed as follows:

- Open the applications menu;
- Open the *Messaging* application;
- From the bottom-right side of the screen touch *Compose new message* symbol;
- Write the message;

Note: You create an MMS by touching the “+” symbol and adding media content: images, sound or movies.

- In the top text box add the number or the name of the recipient;
- Tap the *arrow ->* symbol from the right side of the text box to send the message.

Contacts

Access the Contacts from menu applications.

Add new contact:

- Open *Contacts* from main menu;
- Tap the + symbol from the bottom-right side of the screen;
- Select the memory where you will store: account or phone entry;
- Enter contact information;
- Finally, tap Save.

Add new contact from call log:

- From the applications menu, open the *Dialer*;
- Tap the phone number you want to save;
- Tap *New contact* button;
- Select the memory where you will store: account or phone entry;
- Enter contact information;
- Finally, tap Save.

Import/export contacts

You can import or export contacts between memories and accounts available, as follows:

- Open *Contacts*;
- Press the *Options* button and select *Import/Export*;
- Choose a memory from which to copy contacts;
- Choose in which memory to copy the contacts;
- Select contacts to copy;
- Press the Copy button;

Synchronize contacts with an account

Note: If you don't have an account, you can create one which is also necessary for Google Play.

You can synchronize the contacts of an account by following the next steps:

- Open the applications menu -> Settings -> Applications -> ACCOUNTS;
- Touch the desired account; if you don't have one already set, you can add a new one by touching the button *Add new account*;
- Tick the option *Sync contact*;

Customize contacts with photo

Note: The contacts from SIM card cannot be customized with photo.

To add a photo to a contact, follow the steps:

- Open *Contacts*;
- Touch the desired contact name;
- On the top-right of the screen, touch the contact editing symbol;
- In the left corner of the screen, touch the symbol to add image;
- Select the input method of image: photoshoot or from gallery.

Google Play

Google Play provides a multitude of applications from various categories: games, business, communication, shopping, travel, entertainment, books, education, finance, photography, tools, media, social, sports, news.

The first time you open Google Play, you will be prompted to authenticate. If you already have a Google™ account, enter the data. If not, click the Create button to create a new account and follow the steps on the screen.

Settings

Your service provider may default some device settings, so you may not be able to change these settings.

WLAN

Touch Wi-Fi switch to activate. Open Wi-Fi to search for available networks automatically. Networks without password can be used directly, for others, you need to enter the password first.

Bluetooth

Touch Bluetooth switch to activate. Touch Bluetooth to enter the device searching screen. You can modify settings by pressing the Menu button.

Data usage

Here you can activate or deactivate the data connection and see a chart of data usage status. You can also set the data mobile limit for each SIM.

More

Airplane mode.

Virtual Private Networks (VPN) Settings.

Tethering & portable hotspot.

Mobile network.

Sounds

This option allows you to set audio tones for incoming calls, e-mail alerts and SMS notifications.

Settings include: Vibration, Volume, Tone Audio, Reviews.

Select General/Silent/Meeting/Outdoor profile by touching the right side circle.

Power Saving

You can choose one of the three power schemes:

-Closed.

-Normal: calling and messaging are available; data connection remains the same state.

-Super-long standby: calling and messaging services remain in the same state.

Display

a. Brightness: adjust the brightness.

b. Wallpaper: change the wallpaper picture for idle screen, lock screen and main menu.

- c. Auto rotating screen: rotate phone to change direction.
- d. Sleep: adjust the delay before the screen automatically locks.
- e. Font size.

Battery

Displays information about the charging status and usage of the battery.

Applications

Shows the list of the installed and downloaded applications, which of them are installed on SD CARD.

Location

Access to my location: enable applications to use your location information.

GPS satellites: switch on/off the GPS receiver.

Google Location Service: let applications to use the WiFi or mobile network connection to get localization.

Security

- 1) Set up screen locks: you can choose slide, pattern, PIN or password to unlock the screen.
- 2) Set up SIM card lock: enter 4-8 numbers PIN to set the SIM lock. If you enter the PUK code 10 times wrong, the SIM card will be permanently locked.
- 3) Password visible: visible password when enter it.

- 4) Select device administration: add or delete device manager.
- 5) Unknown sources: install apps from unknown sources.
- 6) Trusted credentials: show the trusted credentials.
- 7) Install from SD card: install the encrypted certificate from SD card.

Languages and input

- 1) Selecting Language: includes all the languages from the phone.
- 2) Spell checker.
- 3) Personal Dictionary: add words to custom dictionary or delete.
- 4) Input method.
- 5) Text to speech settings.
- 6) Pointer speed.

Reset to factory settings

Backup my data: backup my settings and data of other applications.

Factory data reset: clear all data stored on the phone.

Accounts

Add, manage and change synchronization options for the used accounts.

Date and Time

- 1) Automatic date & time: use date and time provided by network or by GPS.
- 2) Automatic time zone: check to use network-provided time zone.
- 3) Set Date/Set time: touch to set date/time.
- 4) Selecting time zone: Select time zone according to where you are.
- 4) Use a 24-hour time format: ON/OFF.

Schedule power on/off

You can set time of boot or close the phone.

Accessibility

1. Power button ends the call.
2. Touch and hold delay.

About phone

You can check the information about: phone status, legal information, software version.

